

AXIS P5514 PTZ Dome Network Camera

Cost-effective, indoor PTZ dome camera

AXIS P5514 is a compact pan/tilt/zoom camera that enables users to pan 360° for overview surveillance and zoom 12x with autofocus for detailed views. It provides HDTV resolution up to 720p at 50/60 fps frame rate. Day/night functionality ensures maintained image quality even in low light conditions. With an optional multi-connector cable, AXIS P5514 supports two-way audio, audio detection, I/O ports for external devices, and AC/DC power. The camera ensures protection against dust and dripping water, allowing it to operate even when a sprinkler system is activated. The SD/SDHC slot enables local video storage.

- > [12x optical zoom](#)
- > [360° pan with Auto-flip](#)
- > [Axis' Zipstream technology](#)
- > [Protection against dust and water](#)
- > [Easy installation including Power over Ethernet](#)



AXIS P5514 PTZ Dome Network Camera

Camera		Storage: Disruption, Recording System: System ready Time: Recurrence, Use schedule
Image sensor	1/2.3" progressive scan CMOS	Event actions Day/night mode, overlay text, video recording to edge storage, pre- and post-alarm video buffering, send SNMP trap PTZ: PTZ preset, start/stop guard tour File upload via FTP, SFTP, HTTP, HTTPS network share and email Notification via email, HTTP, HTTPS and TCP External output activation, play audio clip
Lens	3.8–42.9 mm, F1.4–2.1 Horizontal field of view: 59.2°–5.2° Vertical field of view: 33.3°–3.1° Autofocus, Auto-iris	
Day and night	Automatically removable infrared-cut filter	Data streaming Event data
Minimum illumination	Color: 0.7 lux at 30 IRE F1.4 B/W: 0.08 lux at 30 IRE F1.4	
Shutter time	1/8000 s to 1/30 s at 60 Hz 1/8000 s to 1/25 s at 50 Hz	Built-in installation aids Pixel counter
Pan/Tilt/Zoom	Pan: 360° (with auto-flip), 1.8°–100°/s Tilt: 180°, 1.8°–100°/s 12x optical zoom, 10x digital zoom, total 120x zoom E-flip, Auto-flip, 100 preset positions, Limited guard tour, Control queue	General
Video		Casing IP51-rated Aluminum and plastic casing, polycarbonate (PC) dome
Video compression	H.264 (MPEG-4 Part 10/AVC) – Baseline, Main and High Profiles Motion JPEG	Memory 512 MB RAM, 256 MB Flash
Resolutions	1280x720 to 320x180	Power Power over Ethernet (PoE) IEEE 802.3af/802.3at Type 1 Class 3 Camera consumption: typical 6.3 W, max 12.95 W Multi-connector cable: 20–24 V AC, typical 11 VA, max 22 VA 20–28 V DC, typical 6 W, max 13.5 W (PoE midspan and power supply not included)
Frame rate	Up to 60/50 fps in all resolutions	Connectors RJ45 10BASE-T/100BASE-TX PoE Multi-connector (cable not included) for AC/DC power, 4 configurable alarm inputs/outputs, mic in, line mono input, line mono output to active speaker
Video streaming	Multiple, individually configurable streams in H.264 and Motion JPEG Axis' Zipstream technology in H.264 Controllable frame rate and bandwidth VBR/MBR H.264	Storage Support for SD/SDHC/SDXC card (not included) Support for recording to dedicated network-attached storage (NAS) For SD card and NAS recommendations see www.axis.com
Image settings	Compression, Brightness, Sharpness, White balance, Exposure control, Backlight compensation, WDR – Dynamic Contrast, Fine tuning of behavior at low light, Rotation, Text and image overlay, Image freeze on PTZ	Operating conditions 0 °C to 50 °C (32 °F to 122 °F) Humidity 15–85% RH (non-condensing)
Audio		Storage conditions –40 °C to 65 °C (–40 °F to 149 °F)
Audio streaming	Two-way, full duplex	Approvals EN 55022 Class A, EN 61000-3-2, EN 61000-3-3, EN 55024, EN 61000-6-1, FCC Part 15 Subpart B Class A, ICES-003 Class A, VCCI Class A, RCM AS/NZS CISPR 22 Class A, KCC KN22 Class A, KN24, IEC/EN/JUL 60950-1, IEC 60068-2, IEC 60721-4-3 Class 3K3, 3M3 +B38 EN 61000-6-2
Audio compression	AAC-LC 8/16 kHz, G.711 PCM 8 kHz, G.726 ADPCM 8 kHz Configurable bit rate	Weight 1.1 kg (2.4 lb)
Audio input/output	Requires multi-connector cable (sold separately) for external microphone or line input, and line output	Included accessories Smoked dome cover, Mounting kit for hard and drop ceilings Installation Guide, Windows decoder 1-user license
Network		Optional accessories T91 Mounting Accessories, AXIS T94A03L Recessed Mount Kit Multi-connector cable for AC/DC power, I/Os and audio
Security	Password protection, IP address filtering, HTTPS ^a encryption, IEEE 802.1X ^a network access control, Digest authentication, User access log, Centralized Certificate Management	Video management software AXIS Companion, AXIS Camera Station, Video management software from Axis' Application Development Partners available on www.axis.com/techsup/software
Supported protocols	IPv4/v6, HTTP, HTTPS ^a , SSL/TLS ^a , QoS Layer 3 DiffServ, FTP, SFTP, CIFS/SMB, SMTP, Bonjour, UPnP TM , SNMP v1/v2c/v3(MIB-II), DNS, DynDNS, NTP, RTSP, RTP, TCP, UDP, IGMP, RTCP, ICMP, DHCP, ARP, SOCKS, SSH	Languages English, German, French, Spanish, Italian, Russian, Simplified Chinese, Japanese, Korean, Portuguese, Traditional Chinese
System integration		Warranty Axis 3-year warranty and AXIS Extended Warranty option, see www.axis.com/warranty
Application Programming Interface	Open API for software integration, including VAPIX [®] and AXIS Camera Application Platform; specifications at www.axis.com AXIS Video Hosting System (AVHS) with One-Click Connection ONVIF Profile G, specification at www.onvif.org	
Analytics	Audio detection Video motion detection, Advanced Gatekeeper Support for AXIS Camera Application Platform enabling installation of third-party applications, see www.axis.com/acap	
Event triggers	Detectors: Live stream accessed, Video motion detection, Audio detection Hardware: Fan, Network, Temperature Input Signal: Digital Input Port, Manual trigger, Virtual inputs PTZ: Error, Moving, Preset reached, Ready	

a. *This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (www.openssl.org), and cryptographic software written by Eric Young (ey@cryptsoft.com).*

Environmental responsibility:

www.axis.com/environmental-responsibility